

ELECTRIC TOOL PARTS LIST

■ CORDLESS RECIPROCATING SAW

2022 • 06 • 30

Model CR 18DB

(E1)



